



---

## **SUNSPOT™ USER GUIDE**

- The SUNSPOT is primarily designed to provide a short-term or emergency charge, and should not be a substitute for your devices' recommended charging method.
- Remove the protective plastic cover on the face of the SUNSPOT.

### **ELECTRICAL CHARGE:**

- Using the USB cord, plug the SUNSPOT into the AC adaptor provided (please note other adaptors may not work properly). While charging, the red light will illuminate. Charging a fully depleted SUNSPOT may take 2-4 hours. When the SUNSPOT is fully charged, the red light will turn OFF. *Please note the green light on the SUNSPOT will illuminate whenever there is solar or UV light energy present (whether it's fully charged or not).*

### **SOLAR CHARGE:**

- Place the SUNSPOT directly in the sun. The green light will illuminate when solar/UV energy is present. It will take 10 hours or more to fully charge the SUNSPOT with only solar power depending on your geographic location. You can keep the SUNSPOT clipped on your bag or in the golf cart (exposed to sunlight) and it will build/maintain a charge for later use.

### **CHARGING YOUR GPS/CELL PHONE/MP3 PLAYER:**

- Choose the correct adaptor head for your electronic device and attach it to the adaptor cable. Connect the mini-USB end of the cable to the SUNSPOT and the other (compatible) end to your device. You will see that your device is charging when your device's battery icon is illuminated or flashing. You can use your device while it's charging. Depending on your device, it may take up to 2 hours for the SUNSPOT to charge your device.

### **CAUTION:**

- DO NOT expose to water/extreme moisture. SUNSPOT is not waterproof.
- DO NOT scrape or damage the solar panel.

**ATTENTION! DO NOT RETURN TO RETAILER!**

If you have any problems or questions regarding the SUNSPOT,  
Please call or e-mail IZZO Golf (1-800-284-1220/sales@izzo.com)